





INSTRUCTION MANUAL





BACK TO CORNER/WALL BATHTUB

TOOLS AND MATERIALS REQUIRED




Adjustable Feet



No.	PARTS	Artical No.
A1	NUT	02.LM-WLJLM
A2	Bathtub's foot	02.TJLG

Drain Parts




No	PARTS	Artical No.
B1	D9 Drain cover	03.DYG.D9-1
B2	D9 Drain cover seal ring	03.D9-2
B3	D9 Bouncing core	03.D9-3
B4	D9 Drain head	03.D9-4
B5	D9 Upper seal ring of drain head	03.D9-5
B6	D9 Lower seal ring of drain head	03.D9-6
B7	D9 Drain Sleeve	03.D9-7




Inspect the bathtub for damage before installation

INSTALLATION

Step 1




Step 2



Step 3



Step 4




Step 5



Step 6





The bathtub is made of acryl and can be cleaned with a damp cloth and water with a mild detergent. Household detergents with aggressive, chlorinated and/or abrasive constituents may not be used because this will damage the surface of the bathtub. Limescale can best be removed with a product based on citric acid. However, never use acetic acid, the acryl surface material will be irreversible damaged.